

IMPORTANT INSTALLATION INFORMATION

Prior to installation of the Maximus please follow this simple check to prevent leakage



Fig 1 (screws)



Fig 2 (water tank)



Fig 3 (exposed baffle)



Fig 4 (tighten baffle)



Fig 5 (baffle pipe and shelf)

1. Unscrew and remove two screws at the rear of the unit (1) and slide up the cooler's top cover to expose the water tank (2).
2. Unclip the top forward and rear latches of the cold tank cover (2) to open the top of the water tank and expose the water baffle (3) which separates cold and ambient water.
3. **Check and ensure the baffle fits tightly (4). It should allow water to flow around its sides, but should not be loose.**
4. If it is loose, push down and ensure the baffle pipe fits tightly on the protruding "shelf" (5).
5. Ensuring the push fittings on top of cold tank cover have not loosened, reattach the cold tank cover .
6. Connect the cooler to mains water, monitoring closely the cooler while the tank fills and make sure the float valve shuts off the water.
7. Put the coolers top cover back on, screw top cover back in position.

